

# User's Guide

(for distributors and OEM or special trained personal only)


## Communication-program

for TCU Version TLR 4.3

TLR 4.5

TLR 4.6

(ROTAX® Engine Type 914 Serie)



00684

### **⚠ WARNING**

Before starting with any calibration work on the engine read the User's Manual for TCU versions in its entirety as it contains important safety relevant information.

**Edition: 0 of 1999 09 01**

These technical data and the information contained therein are property of ROTAX® GmbH and must not be reproduced, neither in entirety nor partially, and passed on to third parties without previous consent in writing by ROTAX® GmbH. This text must be written on every complete or partial reproduction.

**Copyright - ROTAX® GmbH**

<b>1) Table of contents .....</b>	<b>2</b>
<b>2) Index .....</b>	<b>4</b>
<b>3) Introduction .....</b>	<b>6</b>
3.1) Remarks .....	6
3.2) Engine serial number .....	6
3.3) Serial number of Dongle (decoding unit), of TCU (turbo control unit) and .....	6
Program version .....	6
<b>4) Safety .....</b>	<b>6</b>
4.1) Repeating symbols .....	7
4.2) Technical documentation .....	7
<b>5) Scope of the communication program (distributor-version) .....</b>	<b>10</b>
<b>6) Supply volume of the calibration set .....</b>	<b>10</b>
<b>7) Required hardware-items (PC) .....</b>	<b>10</b>
<b>8) Establishing of the required hardware connection (TCU - PC) .....</b>	<b>11</b>
<b>9) Software-requirements (PC) .....</b>	<b>12</b>
<b>10) Software TLR 4.3, TLR 4.5 and TLR 4.6 .....</b>	<b>12</b>
<b>11) Installation of the communication program on the PC .....</b>	<b>12</b>
11.1) Entry in MS-DOS .....	12
11.2) Transfer of the software from the floppy-disk to fixed disk of PC .....	12
<b>12) Application of the communication program .....</b>	<b>13</b>
12.1) Entry of the program .....	13
12.2) Start of the program .....	13
12.3) Choice of the graphic adapter .....	13
12.4) Choice of interface .....	14
<b>13) Communication program TLR 4.3, 4.5 and 4.6 .....</b>	<b>16</b>
13.1) Menu control and description of the user's display: .....	16
13.1.1) Menu control .....	16
13.1.2) User's display .....	16
13.2) On-line-menu .....	17
13.2.1) Monitor-menu (data display) .....	18
13.2.1.1) Monitor-menu (TLR 4.6 complete version) .....	19
13.2.1.2) LOG-submenu .....	21
13.2.2) 1_SCOPE-menu .....	24
13.2.3) 2_SCOPE-menu .....	25
13.2.4) CFG/DAT-menu .....	26
13.2.4.1) SETUP-submenu .....	26
13.2.4.2) CALIBRATE-submenu .....	28
READ_CALIBRATION .....	28
TRANSMIT_CALIBRATION .....	29
13.2.4.3) READ_DATA-submenu .....	30
13.2.4.4) VIEW_DATA-submenu .....	31
13.2.4.5) PRINT_DATA-submenu .....	34
13.2.5) Check and calibration of the throttle potentiometer .....	35
13.2.5.1) Checking of the throttle position .....	35
13.2.5.2) THROTTLE-menu (Calibration) .....	36

13.3) TCU-Control data .....	39
13.3.1) FILE_menu .....	39
13.3.2) EDIT-menu .....	40
13.3.2.1) MAP-submenu .....	40
13.3.2.2) FUNCTIONS-submenu .....	41
PRESSURE(Load)-submenu .....	41
TEMP_CORR-submenu .....	42
KNOCK_CORR-submenu .....	42
SERVO_CORR-submenu .....	44
13.3.2.3) CONSTANTS-submenu .....	45
13.3.3) PROM_submenu .....	46
13.4) End of program .....	46
<b>14) Schematic arrangement of control items of Turbo charger control .....</b>	<b>47</b>
<b>15) Chart of program items .....</b>	<b>48</b>
<b>16) ERROR Detection Chart.....</b>	<b>50</b>

## 2) Index

### A

Application of the communication program 13

### C

CALIBRATE-submenu 28

Calibration set 10

CFG/DAT-menu 26

Chart of program items 48, 50

Calibration of the throttle potentiometer 35

Choice of interface 14

Choice of the graphic adapter 13

Communication program 10

CONSTANTS-submenu 45

### D

DATE 21

### E

EDIT-menu 40

End of program 46

Engine serial number 6

Entry in MS-DOS 12

Entry of the program 13

ERROR Detection Chart 50

### F

FILE\_menu 39

FUNCTIONS-submenu 41

### G

Graphic adapter 13

### H

Hardware connection (TCU - PC) 11

Hardware-items 10

### I

Introduction 6

### K

KNOCK\_CORR-submenu 43

### L

LOG-submenu 21

### M

MAP-submenu 40

Menu control 16

Monitor-menu (data display) 18

### O

On-line -menu 17

### P

PRINT\_DATA 34

PROM\_menu 46

### R

READ\_CALIBRATION 28

READ\_DATA 30

Remarks 6

### S

Safety 6

Schematic arrangement 47

SCOPE-menu 1 24

SCOPE-menu 2 25

Serial number of Dongle 6

Serial number of engine 6

SERVO\_CORR-submenu 44

SETUP-submenu 26

Software-requirements (PC) 12

Start of the program 12

### T

TCU-Control data display 39

Technical documentation 7

TEMP\_CORR-submenu 42

THROTTLE-menu (Calibration) 36

TIME 21

TRANSMIT\_CALIBRATION 29

TRANSMIT\_SETUP 26

### U

User's display 16

### V

VIEW\_DATA 31

Blank page

### 3) Introduction

Before starting with the calibration program on the engine, read the User's Manual carefully. It provides you basic information on safe operation of the engine.

If any passages of the Manual are not understood or in case of any questions, please, contact an authorized Distribution- or Service Partner for ROTAX® aircraft engines.

#### 3.1) Remarks

This User's Manual is to acquaint maintenance service staff approved by the local aviation authorities with some basic maintenance and safety information for service works.

For competent maintenance and servicing, please, refer to the documentation provided in the Maintenance Manual, Operator's Manual, Installation Manual and Illustrated Parts Catalog.

For additional engine-, maintenance- and parts information you may also contact the nearest ROTAX® aircraft engine distribution partner.

#### 3.2) Engine serial number

On all enquiries or spare parts orders, always indicate the engine serial number, as the manufacturer makes modifications to the engine for further development. The engine serial number is on the top of the crankcase, magneto side.

#### 3.3) Serial number of Dongle (decoding unit), of TCU (turbo control unit) and Program version

On inquiries regarding TCU, Dongle and Communication program always state serial number of the TCU, of Dongle and of calibration program version, as the manufacturer makes modifications for further development. The serial number is directly on the TCU and Dongle. The version of the calibration program is stated on the information line of the communication program.

### 4) Safety

Although the mere reading of such an instruction does not eliminate a hazard, the understanding and application of the information will promote correct use.

The information and components-/system descriptions contained in this User's Manual are correct at the time of publication. ROTAX® however, maintains a policy of continuous improvement of its products without imposing upon itself any obligation to install them on its products previously manufactured.

ROTAX® reserves the right at any time to discontinue or change specifications, designs, features, models or equipment without incurring obligation.

The illustration in this Maintenance Manual show the typical construction. They may not represent in full detail or the exact shape of the parts which have the same or similar function.

Specifications are given in the SI metric system with the USA equivalent in parenthesis. Where precise accuracy is not required, some conversions are rounded off for easier use.

Page 6	Date 1999 09 01	Subject: TLR 4.3 TLR 4.5 TLR 4.6	Reference	Initial issue
-----------	--------------------	--	-----------	---------------

#### 4.1) Repeating symbols

This Manual uses the following symbols to emphasize particular information. These indications are important and must be respected.

▲ **WARNING:** Identifies an instruction which, if not followed, may cause serious injury including the possibility of death.

■ **ATTENTION:** Denotes an instruction which, if not followed, may severely damage the engine or other components.

◆ **NOTE:** Indicates supplementary information which may be needed to fully complete or understand an instruction.

#### 4.2) Technical documentation

The information given in the

- ☞ Installation Manual (IM)
- ☞ Operator's Manual (OM)
- ☞ Maintenance Manual (MM)
- ☞ Repair Manual (RM)
- ☞ Illustrated Parts Catalog (IPC)
- ☞ Service Bulletin (SB)
- ☞ Service Instruction (SI)
- ☞ Service Letter (SL)

is based on data and experience that are considered applicable for professionals under normal conditions.

■ **ATTENTION:** Due to the fast technical progress and fulfillment of particular specifications of the customers it may occur that existing laws, safety prescriptions, constructional and operational regulations cannot be transferred completely to the object bought, in particular for special constructions, or may not be sufficient.

◆ **NOTE:** The illustrations in this User's Manual are stored in a graphic data file and are provided with a consecutive irrelevant number.

This number (e.g. 00277) is of no significance for the content.

Initial issue	Reference	Subject: TLR 4.3 TLR 4.5 TLR 4.6	Date 1999 09 01	Page 7
---------------	-----------	--	--------------------	-----------

Blank page

Page 8	Date 1999 09 01	Subject: TLR 4.3 TLR 4.5 TLR 4.6	Reference	Initial issue
-----------	--------------------	--	-----------	---------------



## 5) Scope of the communication program (distributor-version)

- ⇒ Verification of function of all sensors and pick-ups
- ⇒ Check of throttle potentiometer (throttle position)
- ⇒ On-line data recording of the turbo control
- ⇒ quick analysis of errors

With this program a prompt analysis of defects and irregularations can be conducted.

Further tasks showing the difference to communication programs TLR 4.Xa (customer version):

- ⇒ Input of engine serial number and hours of operation
- ⇒ Calibration of the throttle potentiometer
- ⇒ Display of TCU control data

## 6) Supply volume of the calibration set

See fig. 1.

- ⇒ Decoding unit (Dongle) with data cable to link with computer
- ⇒ Communication program TLR 4.3, 4.5 or 4.6: Software between TCU and computer




fig. 1

◆ NOTE: For the Monitoring Program tlr. 4.6a no decoding unit (Dongle) is required. Just connect the TCU and the PC via the plug connector RS 232 with the COM (1) interface.

## 7) Required hardware-items (PC)

See fig. 2 and fig. 3.

- ⇒ PC with processor 80 286 or higher level, with
- ⇒ random access memory min. 640 KB RAM
- ⇒ graphic adapter EGA, CGA or VGA
- ⇒ serial interface COM 1 oder COM 2
- ⇒ floppy disk drive 3,5 inch

◆ NOTE: We recommend a Laptop- or Notebook-computer since these units can be utilized also directly on engine or aircraft.

- ⇒ decoding unit (Dongle) ① with data cable to link with computer





fig. 2




fig. 3

## 8) Establishing of the required hardware connection (TCU - PC)

See fig 4 and 5.

➔ Connect decoding unit (Dongle) with 9-pin port of cable harness **2**.

➔ Connect data cable of decoding unit (Dongle) with the **COM1** or **COM2** interface of computer **3**.

◆ **NOTE:** The computer is normally provided with two serial interfaces **4** and **5** (9- or 25-pin).

Normally a serial interface (usually a 9 pin port) is used for connection of a mouse.

Since there is no need for a mouse to control the communication program the Dongle can be connected with the interface for the mouse, best known as COM 1.




fig. 5

### Allocation of the software for establishing of the TCU data.


◆ **NOTE:**

Use: TLR4.3 for the TCU part no. 966.470

TLR4.5 for the TCU part no. 966.471  
part no. 966.472  
part no. 966.473

TLR4.6 for the TCU part no. 966.741

## 9) Software-requirements (PC)



00210

Bild 6

See fig. 6.

- ⇒ operating system MS-DOS 5.0 or higher level
- ⇒ communication program: software linking TCU with computer

◆ NOTE: The communication program TLR 4.3, TLR 4.5 and TLR 4.6 is part of the calibration set.

## 10) Software TLR 4.3, TLR 4.5 and TLR 4.6

⇒ The Software is property of ROTAX<sup>®</sup>. Duplication is only permitted for transmission on a fixed disk or for back up and filing.

⇒ The communication program is defined for use of MS-DOS and should be loaded only with MS-DOS.

◆ NOTE: Only that warrants a stable ON-line operation.

## 11) Installation of the communication program on the PC

◆ NOTE: This procedure has to be performed only once for installation of the communication software from the diskette onto the fixed disk integrated in the computer.

### 11.1) Entry in MS-DOS


See fig. 7.

⇒ Make sure which TCU part no. matches with which program version.

⇒ Switch on the PC and wait for the message **C:\>**

◆ NOTE: If this message should not appear (e.g. immediate start of a Windows-version (WINDOWS 95) change over to MS-DOS-level.

fig. 7



04732

### 11.2) Transfer of the software from the floppy-disk to fixed disk of PC

⇒ Insert program floppy disk into the drive "A" and enter the command

**C:\>XCOPY\_A:\*. \*\_C:\\_ /s [Enter]**

(enter only bold face printed command).

◆ NOTE: With this command the directory "914/progXX" with all its sub directories will be established.

⇒ Remove floppy-disk from drive and store safely.

■ ATTENTION: Perform installation of the program every time with the original floppy-disk.



⇒ With this information, together with the COM-interface choice (as per next point) a configuration file will be opened with the title **tlr.cfg** in the dictionary C:\914\progXX\>.

If wrong choice should have been made delete this sub file with the MS-DOS command

C:\914\progXX\>**del tlr.cfg [Enter]**

and start the communication program anew.

## 12.4) Choice of interface

See fig. 9.

◆ NOTE: Choice of the interface is not possible when using the software TLR 4.3.

◆ NOTE: Selection of monitor display only at the very first entry in the communication program. Select the appropriate configuration for the computer.

⇒ further select the correct COM-port (see fig. 9.) Enter the used COM interface by pressing the key:

1 for **COM**-port 1

2 for **COM**-port 2

fig. 9



00189

⇒ With this information, together with the chosen graphic adapter a configuration file with the title **tlr.cfg** will be opened in the directory C:\914\progXX\>. If a wrong choice should have been made delete this sub file with the MS-DOS command

C:\914\progXX\>**del tlr.cfg [Enter]**

and start the communication program anew.

Blank page

# 13) Communication program TLR 4.3, 4.5 and 4.6

## 13.1) Menu control and description of the user's display:

### 13.1.1) Menu control

See fig. 10.

The subprograms are always listed on the menu line and will be activated by input of the first letter of the program e.g. "M" for MONITOR (monitoring program)

◆ NOTE: The key "ESC" will transfer you to the superordinated menu.

### 13.1.2) User's display

#### Program information line:

This line will inform the user about version and type of the program.

#### Menu line:


On this line all the retrievable sub programs are listed.

#### Sub programs:

Are called up as stated above and are branching to the individual options of the sub menu.

◆ NOTE: The illustration shows the communication programs TLR 4.3, TLR 4.5 and TLR 4.6

fig. 10



## 13.2) On-line-menu

See fig. 11.

- ⇒ These menus serve for the on-line display of engine data at the very moment, such as engine speed, throttle position, airbox pressure etc. which are imperative for maintenance and error detection.

### On-line display:

- ⇒ These sub menu are only available in conjunction with an active TCU and Dongle. (not for version TLR 4.6a)

- ◆ NOTE: If at start of the on-line subprograms (MONITOR, 1\_SCOPE, 2\_SCOPE aso.) the error message

**"/ERROR: Serial I/O Continue with any key..."**

should appear in the last line ❶ a connection between TCU and computer is interrupted. Checking of all plug connections between TCU and computer is necessary. In addition verify voltage supply to TCU.

Correct any detected interruption between TCU and computer and switch "OFF" and "ON" TCU power supply.



fig. 11

00191

### 13.2.1) Monitor-menu (data display)


See fig. 12.

#### MONITOR:

Serves for the on-line display of operational engine data such as airbox pressure, ambient pressure, servo position airbox temperature etc.


fig. 12

#### TLR 4.3



03903

#### TLR 4.5



03909

#### TLR 4.6



03904


### 13.2.1.1) Monitor-menu (TLR 4.6 complete version)

See fig. 12 a.

Program TLR 4.6 with facility of display of all engine operating data by fast change-over to "ON-LINE".


```
TLR V4.6 (COM1:)< > (c) CONTEC 1998
MAIN MENU: EDIT FILE PROM MONITOR 1_SCOPE 2_SCOPE CPG/DAT THROTTLE QUIT
```

03902



04720

By pressing the keys **CTRL + M** the following monitor display will appear.(in the main menu only)



This monitor display represents the most important program unit for maintenance. Especially for error analysis, the monitor menu offers some options. It enables verification of indicated values and comparison with the engine instruments in the aircraft. For single error detection, the "Error Detection Chart" in section 16 may be utilized.

## Legend to monitor display

- ❶ **engine speed**
- ❷ **throttle position**
- ❸ **ambient pressure**
- ❹ LOG-state ON/OFF
- ❺ target pressure input on basis of throttle position
- ❻ target pressure input on basis of pressure between ❸ and ❸
- ❼ effective target pressure input (possibly reduced for instance by over-speed, airbox temperature or too high pressure ratio)
- ❽ **airbox pressure**
- ❾ pressure difference to ❷ and ❸
- ❿ no meaning (controller data)
- ⓫ actual wastegate position
- ⓬ not active
- ⓭ target pressure reduction by exceeding of the max. airbox temperature
- ⓮ target pressure reduction by excessive engine speed
- ⓯ **airbox temperature**
- ⓰ knocking signal: not active
- ⓱ logging ON/OFF
- ⓲ software status
- ⓳ subprogram designation
- ⓴ range of modulation for servo motor
- ⓵ deviation of ⓫ and ⓬
- ⓶ target position of wastegate
- ⓷ correction factor for wastegate position by PID-controller
- ⓸ target input of wastegate position in correlation to ❷ and ❸
- ⓹ factor "D"
- ⓺ factor "I"
- ⓻ factor "P"
- ⓼ boost period in the past hours (indication in percentage per hour)
- ⓽ boost period since switching ON the TCU (indicated in percentage per hour)
- ⓿ required only for internal evaluation
- ⓿ Shows the loaded software status (see chapt. 13.3)

◆ NOTE: Because if the multitude of indications, parameters important for the user are printed in bold type and underlined.

Page 20	Date 1999 09 01	Subject: TLR 4.3 TLR 4.5 TLR 4.6	Reference	Initial issue
------------	--------------------	--	-----------	---------------

See fig. 13, 14 and 15.

**LOG:**


Is a submenu of the monitoring menu and facilitates recording of the relevant operational data on the hard disk of the connected PC.

The logging will be actuated and stopped by pressing the key **L**. The logging state will be indicated by "ON" for on-line recording and "OFF" respectively for nonrecording (see fig. 13, item **1**).

◆ NOTE:

The illustration shows the program version TLR 4.6

fig. 13



03910 |

A so-called Log-file will be loaded on a **hard disk** starting date and starting time of the recording.

Example:

11061014.LOG

- Minute (minute)
- Stunde (hour)
- Tag (day)
- Monat (month)

◆ NOTE:

Verify this date and starting time at start of the PC.  
Use at MS-DOS level the commands

C:\> **DATE [Enter]** and

C:\> TIME [Enter]

and up-date as per input command date and time.

If more than 4000 data lines are recorded the current LOG file will be closed automatically and a new one opened.

Subsequent to recording the data can be stored on a diskette or printed for evaluation.

⇒ data transfer to diskette:  
with the command

C:\914\progXX> DIR\*.log [Enter]

read list of log-files on MS-DOS Monitor.

After finding the requested LOG file, data can be transferred to diskette by command line

C:\914\progXX\>COPY\_C:\FILE-Name\_A:\

e.g. 11061014.log

The thus established LOG-files are text files which can be used for further data editing in text-and table calculation programs.

The fig. 14 illustrates data in program version TLR 4.3 on our EXCEL table.

◆ NOTE: The illustration shows program version TLR 4.3

time PC (hh:mm:ss)	speed (1/min)	load throttle (0-115%)	pressure difference (mbar)	nominal pressure (mbar)	actual pressure (mbar)	ambient pressure (mbar)	servo position (0 - 100 zu)	knocking	airbox (°C)	P-factor	I-factor	D-factor	output servo (+/-100)
16:53:01	2388	3,3	-123	1100	977	978	100	500	27,6	20	3	80	0
16:53:01	2384	3,3	-123	1100	977	978	100	495	27,6	20	3	80	0
16:53:02	2386	3,3	-123	1100	977	978	100	495	27,6	20	3	80	0
16:53:02	2369	3,3	-122	1100	978	978	100	528	27,6	20	3	80	0
16:53:02	2387	3,3	-122	1100	978	978	100	526	27,6	20	3	80	0
16:53:02	2388	3,3	-122	1100	977	978	100	526	27,6	20	3	100	0

00475      1      2      9      5      8      3      11      16      15      27      26      25      20

for above mentioned numbers see also monitor display TLR 4.3

fig. 14

Time	Speed	Load	Pressure Diff	Nominal Pressure	Actual Pressure	Ambient Pressure	Servo Position	Knocking	Airbox Temp	P-factor	I-factor	D-factor	Output Servo
09:49:35	0	62.5	-81	1059	977	980	101	0	24.1	20	3	20	0
09:49:36	0	62.6	-82	1059	978	979	101	0	24.1	20	3	20	0
09:49:36	0	62.6	-82	1059	977	979	101	0	24.1	20	3	20	0
09:49:37	0	62.6	-82	1059	978	979	101	0	24.1	20	3	20	0
09:49:37	0	62.6	-82	1059	977	980	101	0	24.1	20	3	20	0
09:49:37	0	62.5	-81	1059	978	980	101	0	24.1	20	3	20	0

00764

fig.15

The fig. 14a illustrates data of the program version TLR 4.5 in an EXCEL-table.

◆ NOTE: The illustration shows program version TLR 4.5

time PC (hh:mm:ss)	speed (1/min)	load throttle (0-115%)	pressure difference (hPa)	nominal pressure (hPa)	actual pressure (hPa)	ambient pressure (hPa)	knock (not used)	airbox temp. (°C)	MAP servo position	servo offset (+/-20)	servo posit nom.	servo posit act.	difference servo nom - act.	output servo PWM (+/-100)
12:44:06	5750	114,6	110	1350	1236	1019	1	47,8	75	10	85	84,2	0,8	11
12:44:06	5753	114,6	102	1350	1240	1020	1	47,9	75	10	85	84,3	0,7	12
12:44:07	5747	114,6	99	1350	1252	1020	1	47,9	75	10	85	84,3	0,6	13
12:44:07	5756	114,6	93	1350	1258	1019	1	48	75	10	85	84,4	0,5	10
12:44:07	5741	114,6	82	1350	1260	1019	1	48,1	75	10	85	84,4	0,4	10
12:44:10	5749	114,7	49	1350	1301	1019	1	48,7	75	10	85	84,8	0,2	10
12:44:10	5755	114,6	42	1350	1303	1019	1	48,8	75	10	85	84,8	0,3	10
12:44:11	5753	114,6	42	1350	1312	1019	1	48,9	75	10	85	84,7	0,2	10

00167

1 2 9 5 8 3 16 15 24 22 11 21 20

fig. 14 a

for the mentioned numbers see also monitor display TLR 4.5

02251340.log - Editor													
Datei	Bearbeiten	Suchen	?										
13:40:04	0	0.0	538	1500	963	966	0	25.6	92.8	20.0	100.0	100.0	0.0 -2
13:40:05	0	0.0	537	1500	963	966	0	25.5	92.7	20.0	100.0	99.8	-0.1 1
13:40:05	0	0.0	537	1500	963	966	0	25.5	92.7	20.0	100.0	100.1	0.0 1
13:40:06	0	8.1	46	1230	963	965	0	25.5	36.8	2.8	39.6	100.1	-47.8 -100

00642

fig. 15 a

The fig. 14b illustrates data of the program version TLR 4.6 in an EXCEL-table.

◆ NOTE: The illustration shows program version TLR 4.6

time PC (hh:mm:ss)	speed (1/min)	load throttle (0-115%)	ambient pressure (hPa)	actual pressure (hPa)	nominal pressure (hPa)	servo posit act.	airbox temp. (°C)
15:16:13	5750	114.9	972	970	1370	88.4	24.4
15:16:13	5753	114.8	972	970	1370	88.3	24.4
15:16:14	5747	114.8	972	970	1370	88.4	24.4
15:16:14	5756	114.8	972	970	1370	88.4	24.4

03916

1 2 3 8 28 11 15

for the mentioned numbers see also monitor display TLR 4.6

fig. 14 b

06211605.log - Editor							
Datei	Bearbeiten	Suchen	?				
16:05:50	0	114.8	972	969	1370	88.3	24.3
16:05:50	0	114.8	972	969	1370	88.2	24.3
16:05:50	0	114.8	972	970	1370	88.4	24.3
16:05:50	0	114.8	972	970	1370	88.3	24.3
16:05:50	0	114.8	972	970	1370	88.3	24.3
16:05:50	0	114.9	972	970	1370	88.3	24.3
16:05:50	0	114.8	972	970	1370	88.4	24.3

03917

fig. 15 b

Initial issue	Reference	Subject: TLR 4.3 TLR 4.5 TLR 4.6	Date 1999 09 01	Page 23
---------------	-----------	--	--------------------	------------

13.2.2) 1\_SCOPE-menu

See fig. 16 and 17.

**1\_SCOPE:** For on-line display of the control action with regard to pressure deviation (airbox pressure to target pressure) in the range of  $\pm 100$  hPa (mbar).

The menu is for graphic evaluation of the parameters 7 and 8 in the monitor menu.

◆ NOTE: The illustration shows program version TLR 4.5



00586

fig. 16




fig. 17

00194


13.2.3) 2\_SCOPE-menu

See fig. 18 and 19.

**2\_SCOPE:** For on-line display of the control action between target pressure and effective airbox pressure in the range of 1000 to 1400 hPa (mbar).

The menu is for graphic evaluation of the parameters 7 and 8 in the monitor menu.

◆ NOTE: The illustration shows program version TLR 4.5



00586



00195

13.2.4) CFG/DAT-menu

See fig. 20.

**CFG/DAT:** This menu branch serves the user for representation of calibration data and for input of TCU data such as serial number, hours of operation and especially of throttle position. This display is imperative for maintenance and calibration.

◆ **NOTE:** In program version TLR 4.6 the input of the throttle valve data is made automatically (see section. 13.2.5.2)

◆ **NOTE:** The illustration shows program version TLR 4.5



fig. 20

13.2.4.1) SETUP-subprogram

See fig. 21.

**SETUP:** facilitates the setting of the engine number for the respective TCU (input of the last four digits of the engine number) and of the actual period of operation.



fig. 21

TRANSMIT\_SETUP

See fig. 22, 23, 24 and 25.




fig. 22

**TRANSMIT\_SETUP:** After input of engine number and hours of operation store the information by Transmit-Setup in the TCU.

◆ **NOTE:** In program version TLR 4.6 the engine serial number can be put-in in 7 digits.


- ◆ NOTE: In order not to erase the calibration of the TCU press the key "N" for NO before an inquiry. Otherwise the TCU will be reset to default values of the manufacturer and new calibration will be necessary.



00608


fig. 23

- ⇒ At a transfer procedure the process of the data transfer will be indicated in %, in which at 100% the writing is completed and the TCU will be set to input data.



00606

fig. 24



00607

fig. 25

### 13.2.4.2) CALIBRATE-submenu

See fig. 26.

**CALIBRATE:** Is besides the THROTTLE-submenu the most important point of the menu for verification and setting of the calibration data.

```
CONFIGURATION/DATA ACCESS: [ TEMP2 ]
SETUP CALIBRATE READ_DATA VIEW_DATA PRINT_DATA
```

00603

fig. 26

#### READ\_CALIBRATION

See fig. 27 and 28.

**READ\_CALIBRATION:** Reads the topic calibration data from the TCU.

```
WASTE GATE SERVO/THROTTLE: OPEN/IDLE <-----> CLOSED/FULL(=BOOST=115%)
0      200      400      600      800      1000
|-----|-----|-----|-----|-----|
|<--- OFFSET --->|<----- RANGE ----->|

Pressure sensor characteristic curve:  E_out ... Output voltage [V]
E_out = U_s * a * P + b                U_s ..... Supply voltage [V]
                                      P ..... Pressure [mbar]

Calculation of pressure sensor calibration parameters:
A = 5000 / (1023 * a)                  (values of A,B must be rounded to integers)
B = - (b / a)

Servo OFFSET .....
Servo RANGE .....
Throttle OFFSET .....
Throttle RANGE .....
Airbox pressure sensor calibration parameter A .....
Airbox pressure sensor calibration parameter B .....
Ambient pressure sensor calibration parameter A .....
Ambient pressure sensor calibration parameter B .....

CONTROL UNIT CALIBRATION: [ ]
READ_CALIBRATION TRANSMIT_CALIBRATION
```

00609

fig. 27



◆ NOTE: The illustration 28 shows program version TLR 4.3

### TLR 4.3

```
Servo OFFSET ..... 10
Servo RANGE ..... 1003
Throttle OFFSET ..... 79
Throttle RANGE ..... 655
Airbox pressure sensor calibration parameter A ..... 12219
Airbox pressure sensor calibration parameter B ..... 250
Ambient pressure sensor calibration parameter A ..... 6720
Ambient pressure sensor calibration parameter B ..... -37

CONTROL UNIT CALIBRATION: [ ]
READ_CALIBRATION TRANSMIT_CALIBRATION
```

03921

fig. 28

◆ NOTE: The illustration 28a shows program version TLR 4.5 and TLR 4.6

TLR 4.5  
TLR 4.6

Servo OFFSET .....	60
Servo RANGE .....	900
Throttle OFFSET .....	68
Throttle RANGE .....	677
Airbox pressure sensor calibration parameter A .....	12219
Airbox pressure sensor calibration parameter B .....	250
Ambient pressure sensor calibration parameter A .....	6720
Ambient pressure sensor calibration parameter B .....	-37

CONTROL UNIT CALIBRATION:	READ_CALIBRATION	TRANSMIT_CALIBRATION
---------------------------	------------------	----------------------

00610

fig. 28 a

### TRANSMIT\_CALIBRATION

See fig. 29 and 30.

**TRANSMIT\_CALIBRATION:** Serves for transfer of verified and determined calibration data.

CONTROL UNIT CALIBRATION:	READ_CALIBRATION	TRANSMIT_CALIBRATION
---------------------------	------------------	----------------------

00609

fig. 29



■ ATTENTION: Except for the input of THROTTLE offset and THROTTLE range, compare the transfer values, for the relevant program version, as shown in illustration 28 and 28a and correct as required.

TLR 4.5 u. 4.6    TLR 4.3

Servo OFFSET .....	60
Servo RANGE .....	900
Throttle OFFSET .....	68
Throttle RANGE .....	677
Airbox pressure sensor calibration parameter A .....	12219
Airbox pressure sensor calibration parameter B .....	250
Ambient pressure sensor calibration parameter A .....	6720
Ambient pressure sensor calibration parameter B .....	-37

Transmitting Kalibration Data ..... 100 % done	
!!! RESETTING CONTROL UNIT !!!	
TRANSMITTING CONTROL UNIT KALIBRATION:	

10
1003
79
655
12219
250
6720
-37

03922

fig. 30

00611

◆ NOTE: For procedure to receive each relevant THROTTLE offset and THROTTLE range value refer to chapter 13.2.5.

### 13.2.4.3) READ\_DATA-submenu

See fig. 31 and 32.

**READ\_DATA:** Reads data such as serial number, time of operation and the latest transmitted engine data from the storage in the TCU.



00603

fig. 31

After reaching 100% the reading is complete and the data can be displayed on the screen on the sub menu VIEW\_DATA.



00612

fig. 32

◆ NOTE:

If this command should be carried out during establishing of a LOG file the error message **"SERIAL ACCESS DENIED"** will appear..

In this case repeat the reading procedure.

#### 13.2.4.4) VIEW\_DATA-submenu

See fig. 33 and 34.


**VIEW\_DATA:** Shows the file data read from READ\_DATA on the screen. The keys "page up" ↑ and "page down" ↓ enable paging on the screen.

#### PROGRAM-VERSION TLR 4.3 and TLR 4.5

8 control measurements of the last two hours of operation are displayed. The display as well as the recording take place in 6 minute intervals in which the **moment-value** will be stored.

TLR 4.3

TLR 4.5



PROGRAM-VERSION TLR 4.6

See fig. 33a, 34a, 34b, 34c and 34d.

TLR 4.6

7 Measurements of the last 20 minutes of operation are displayed.

fig. 33a




fig. 34a

INTERVALL MEMORY:

The display as well as the recording take place in 1 minute intervals in which the **highest value each time** will be stored.

◆ NOTE:

Since for each channel the max. values within a period (1 min.) are stored, time differences between the max. values may exist.




fig. 34b

### LIFETIME DATA:

Displays and stores exceedings of maximum values during the complete period of operation.




fig. 34c

- ① max. value of channel
- ② time of max. value recording
- ③ number of error messages
- ④ total period of exceeding limits of operation
- ⑤ total period of boost operation

### ALARM RECORDS:

Stores and displays the last 100 exceedings of maximum values in 1 minute intervals.




fig. 34d

03216

### 13.2.4.5) PRINT\_DATA-submenu

See fig. 35 ,36 ,37 and 38.

**PRINT\_DATA:** Offers the option to print data deduced from READ\_DATA.

fig. 35



00196

fig. 36

1

◆ NOTE:

The printer has to be connected with the PC via a parallel interface 1.



fig. 37

◆ NOTE:

If problems should arise regarding connection between computer and printer (e.g. a disconnected printer cable or printer without power) an error message will appear on the menu line.

**"/ERROR: Device I/O (Printer) Continue with any key..."**

Checking of the connection computer with printer is necessary.

◆ NOTE:

The illustration shows program version TLR 4.5

Example of a print-out:

TLR		BOMBARDIER-ROTAX/conTec								
Serial Number		:	500							
Hours of Operation		:	564.1							
----- Intervall Memory -----										
Channel	Input	Unit/Range								
1	SPEED	[Rpm]								
2	LOAD (Throttle-Pos.)	[%]								
3	AIR_PRESSURE	[mbar]								
4	AIRBOX_PRESSURE	[mbar]								
5	AIRBOX_TEMPERATURE	[°C]								
6	SERVO_POSITION	[%]								
7	KNOCK_A/D_VALUE	[0..1023]								
8	BOOST_TIME	[s]								
Mode/Time [h]/Ch.	1	2	3	4	5	6	7	8		
0 564.0	0	0	985	1249	28	-1	0	0		

fig. 38

00205

## 13.2.5) Check and calibration of the throttle potentiometer

### 13.2.5.1) Checking of the throttle position

See fig. 39 and 40.

◆ NOTE: The illustration shows program version TLR 4.6




fig. 39

03904

⇒ Start-up of the submenu MONITOR (see chap. 13.2.1 or 13.2.1.1)

Throttle position is displayed under LOAD ① (for carb. 2/4)

00214

LOAD 0.0 [%]	0 %	⇒ Throttle completely closed
LOAD 115.0 [%]	115 %	⇒ Throttle fully open

00215

fig. 40

⇒ visually check whether the throttle on both carburetors can be fully opened and closed. If necessary correct the installation setting.

⇒ check of the display with throttle completely closed:

**nominal: 0°      tolerance +3%**

⇒ check of the display with throttle fully open:

**nominal: 115 %      tolerance -2%**

■ ATTENTION: Check whether indication is **linear over the complete range** from 0 to 115 % i.e. the 115 % position is not indicated before throttle is fully open.

⇒ Check the display at max. continuous power.

■ ATTENTION: Throttle lever must be in positive stop position.

nominal: 100 % tolerance +3%.

▲ WARNING: This check of position is only meaningful and allowed, if idle- and full throttle-position are within the allowance.

If the throttle position for idle and full throttle are not within the allowance or if not proceeding linear, then a new calibration of the throttle position is absolutely necessary.

### 13.2.5.2) THROTTLE-menu (Calibration)

See fig. 41, 41a, 42, 42a, 43, 43a, 44, 44a, 45, 45a, 45b.

**THROTTLE:** provides the necessary data for calibration of the throttle potentiometer. To receive the relevant data proceed in the following steps:

TLR 4.3

Directions for the program version TLR 4.3 a. TLR 4.5

TLR 4.5

◆ NOTE: The illustration shows program version TLR 4.5

```
TLR U4.5 <COM1:>                                <c> CONTEC 1997
MAIN MENU: EDIT FILE PROM MONITOR 1_SCOPE 2_SCOPE CFG/DAT THROTTLE QUIT
```

00586

fig. 41

⇒ The assignment field indicates to set throttle to idle position. Close the throttle completely.

```

  OFFSET  RANGE  ANALOG_VALUE
OLD:  68    677  IDLE:
NEW:                   FULL:

SET THROTTLE POTENTIOMETER TO IDLE POSITION ..... THEN TYPE <RETURN>


THROTTLE POTENTIOMETER CALIBRATION CHECK: [ 1 ]
```

00615

fig. 42



or



⇒ acknowledge this step by pressing the key RETURN.

⇒ follow the command in the assignment field to set throttle to fully open position.

Acknowledge again with the RETURN key.

fig. 43

```

SET THROTTLE POTENTIOMETER TO FULL LOAD POSITION ..... THEN TYPE <RETURN>

THROTTLE POTENTIOMETER CALIBRATION CHECK: [ 1 ]
```

00616

fig. 44

➡ In the field OFFSET-NEW and RANGE-NEW the relevant throttle parameters appear which have to be put in submenu for THROTTLE offset and THROTTLE range.




fig. 45




fig. 45b

- ➔ Check throttle position after calibration and transfer of data (see chapter. 13.2.4.2)

▲ WARNING: Only check and change the THROTTLE OFFSET and THROTTLE RANGE. The other values have to be compared only with the values on the above display and must not be changed.

## Directions for program version TLR 4.6

**TLR 4.6**

◆ NOTE: The illustration shows program version TLR 4.6

```
TLR U4.6 <COM1:>                                <c> CONTEC 1998
MAIN MENU: EDIT  FILE  PROM  MONITOR  1_SCOPE  2_SCOPE  CFG/DAT  THROTTLE  QUIT
```

03902

fig. 41a

⇒ The assignment field indicates to set throttle to idle position. Close the throttle completely.

```
SET THROTTLE POTENTIOMETER TO IDLE POSITION .....THEN PRESS <RETURN>
.....
THROTTLE POTENTIOMETER CALIBRATION:
```

03931

fig. 42a

- ⇒ acknowledge this step by pressing the key RETURN.
  - ⇒ follow the command in the assignment field to set throttle to fully open position.
- Acknowledge again with the RETURN key.




fig. 43a

```
SET THROTTLE POTENTIOMETER TO FULL LOAD POSITION .....THEN PRESS <RETURN>
.....
THROTTLE POTENTIOMETER CALIBRATION:
```

03932

fig. 44a

⇒ The effective values for THROTTLE Offset and THROTTLE Range are automatically stored and can be seen on the CALIBRATE subprogram (chap. 13.2.4.2)

```
.....CALIBRATION COMPLETE !
.....
THROTTLE POTENTIOMETER CALIBRATION:
```

03933

fig. 45a

◆ NOTE: After calibration and transfer of the data check the throttle valve position (see chap. 13.2.4.2)

### 13.3) TCU-Control data

- ⇒ These program components serve the user display of TCU specific control data and reveal the control response of the TCU.

#### 13.3.1) FILE\_menu

See fig. 46 ,47 ,48 and 49.

**FILE:** For choice of data set, valid for the respective TCU-version and to store date for viewing with the following stated sub menu.



fig. 46

By pressing key L for LOAD, data record valid for this version will be activated.



fig. 47

#### Allocation of the data-set:

TCU part no.	program-vers.	data-set
966 470	TLR 4.3	ROTAX21
966 471	TLR 4.5	ROTAX881
966 472		ROTAX89
966 473		ROTAX99
966 741	TLR 4.6	ROTAX99

Mark the corresponding data set by the CURSOR-key and put in the activated data set with the RETURN-key.


04055



fig. 48

To continue further with the EDIT submenu the data set (e.g. **ROTAX99**) should appear on the program information line.

fig. 49



13.3.2) EDIT-menu

See fig. 50.

EDIT: is the submenu which informs about the TCU control data.

◆ NOTE: The illustration shows program version TLR 4.6 with data set ROTAX99




03902

fig. 50

13.3.2.1) MAP-submenu

See fig. 51 and 52.

MAP: Visualizes the action of the servo motor in response to target input on MAP in correlation to ambient pressure and airbox pressure.



00587

fig. 51

Ambient Pressure								
[mbar]	800	850	900	950	1000	1050	1100	1150
950	900	900	300	300	200	200	200	200
1000	815	755	660	475	360	360	360	360
1050	785	725	655	545	540	540	540	540
1100	775	740	680	620	590	550	550	550
1150	833	795	733	634	600	575	575	575
1200	815	770	706	660	620	600	600	600
1250	830	795	750	678	640	640	640	640
1300	840	795	765	723	680	680	680	680
1350	850	820	780	750	720	720	720	720
1400	905	875	841	812	780	780	780	780
1450	1000	1000	1000	1000	1000	1000	1000	1000
1500	1000	1000	1000	1000	1000	1000	1000	1000
1550	1000	1000	1000	1000	1000	1000	1000	1000
1600	1000	1000	1000	1000	1000	1000	1000	1000
1650	1000	1000	1000	1000	1000	1000	1000	1000
1700	1000	1000	1000	1000	1000	1000	1000	1000

SETPOINT SERVO POSITION [0.1%]: MATH [ ROTAX99 ] <pg\_up/down> <cursor>

01351

fig. 52

### 13.3.2.2) FUNCTIONS-submenu

See fig. 53.

**FUNCTIONS:** provides the submenu for correction of air pressure-and servo motor control.




fig. 53



#### PRESSURE(Load)-submenu

See fig. 54 ,55 ,56 and 57.

**PRESSURE(Load):** Indicates target pressure corresponding to throttle position.



fig. 54




fig. 55

◆ NOTE: The illustration shows data set ROTAX99

0% W.G. open 100% W.G. close




fig. 56






fig. 57

TEMP\_CORR-submenu


See fig. 58, 59 and 60.

TEMP\_CORR: provides the control parameters for correction of the target pressure in response to increased airbox temperature resulting in effective target pressure(see Monitor menu chapt. 13.2.1 ⑦).



◆ NOTE: The illustration shows data set ROTAX99


Druckreduktion [hPa]  
(pressure reduction)



**KNOCK\_CORR-submenu**

See fig. 61 and 62.


**KNOCK\_CORR:** This menu is not active any more and doesn't contain data sets any longer.



SERVO\_CORR-submenu

See fig. 63, 64 and 65.

**SERVO\_CORR:** provides the data set for correction of the wastegate input in correlation to respective airbox temperature (see monitor menu 13.2.1 24).



01352

fig. 64

OUTPUT: SERVOPOSITION		INPUT: TEMPERATURE		TYPE: ADDITIVE	
°C	%	°C	%		
0	-30.0	48	-6.0		
4	-28.0	52	-4.0		
8	-26.0	56	-2.0		
12	-24.0	60	0.0		
16	-22.0	64	2.0		
20	-20.0	68	4.0		
24	-18.0	72	6.0		
28	-16.0	76	8.0		
32	-14.0	80	10.0		
36	-12.0	84	12.0		
40	-10.0	88	14.0		
44	-8.0	92	16.0		

◆ NOTE: The illustration shows data set ROTAX99

Korrektur der Servoposition [%]  
(correction of servoposition)




fig. 65

### 13.3.2.3) CONSTANTS-submenu

See fig. 66, 67 and 68.

**CONSTANTS:** Provides the various constants.




fig. 66


Pressure sensor characteristic curve:  
 $E_{out} = U_s * a * P + b$   
E\_out ... Output voltage [V]  
U\_s ..... Supply voltage [V]  
P ..... Pressure [mbar]  
Calculation of pressure sensor calibration parameters:  
 $A = 5000 / (1023 * a)$   
 $B = - (b / a)$  (values of A,B must be rounded to integers)

Default Airbox Press. Sensor Cal. Parameters:	A .....	12219
	B .....	250
Default Ambient Press. Sensor Cal. Parameters:	A .....	6720
	B .....	-37
Pressure Regulator: P-Parameter (0..5500)	.....	200
I-Parameter (0..32767)	.....	40
D-Parameter (0..5500)	.....	500
Servopos.Regulator: P-Parameter (0..5500)	.....	500
I-Parameter (0..32767)	.....	30
Maximum Servo-Setpoint-Offset from Press. Regulator +/- [%]	.....	30

ROTAX99

CONSTANTS/2: <page up/down> <cursor>

fig. 67



Default Servo OFFSET .....	60
Default Servo RANGE .....	900
Default Throttle OFFSET .....	55
Default Throttle RANGE .....	715
Knock detection start angle (20..180 deg. after ref.signal) .....	20.0
Knock detection angle (0..90 deg.) .....	90.0
Knock limit (knocking = AD_value > knock limit) [0..1023] .....	575
Knock control loop: Time interval for pressure reduction [ 87 ms ] ....	20
Knock control loop: Pressure increment after end of knocking [mbar] ...	20
Knock control loop: Time interval for pressure increase [ 87 ms ] ....	1
Max. pressure ratio (airbox pressure / ambient pressure) .....	2.400
Boostlimit (BOOST = airbox pressure > boostlimit) [mbar] .....	1260
Speed limitation: Speed 1 (Start of pressure reduction) [rpm] .....	5900
Speed limitation: Speed 2 (Max. pressure reduction) [rpm] .....	6500
Speed limitation: Max. pressure reduction (Speed >= Speed 2) [mbar] ...	800

ROTAX99


CONSTANTS/1: <page up/down> <cursor>

fig. 68

13.3.3) PROM\_submenu

See fig. 69.

**PROM:** Is a furter submenu of no application for the user.




03902

fig. 69

13.4) End of program

See fig. 70.

⇒ With "Q" for QUIT stop communication program



03902

fig. 70


- ⇒ Turn off the TCU
- ⇒ Disconnect wiring (store Dongle proper)
- ⇒ Switch off PC

# 14) Schematic arrangement of control items of Turbo charger control

See fig. 71.

This general chart should help you to familiarize yourself with items of turbo charger control and TCU specific control sequence.

◆ NOTE: The illustration shows  
program version  
TLR 4.6



## 15) Chart of program items

See fig. 72 and 72a.

fig. 72

### Program version TLR 4.3

user field	key	point of menu	brief description
	Esc		exit from the respective sub program, back to the main menu
choice of graphic adapter	V	V G A	option to choose VGA-graphic card
	C	C G A	option to choose CGA-graphic card
	E	E G A	option to choose EGA-graphic card
On-line-display <sup>1)2)</sup>	M	MONITOR	display of engine data
	S	STEPSIZE	shows the input of the PID-values
	M	MEMORY	shows the stored values for PID regulator
	C	CLEAR OFFSET	clears limit values
	L	LOG	ON/OFF of engine data recording
	1	1_SCOPE	display deviation (AIRBOX-pressure to SETPOINT-pressure)
	2	2_SCOPE	display (AIRBOX-pressure and SETPOINT-pressure)
Calibration-data <sup>1)</sup>	C	CFG/DAT	submenu, calibration and TCU data analysis
	S	SETUP	submenu for input of serial number and hours of operation
	T	TRANSMIT_SETUP	Setup data transfer to TCU
	C	CALIBRATE	display (SERVO, THROTTLE, pressure sensor)
	R	READ_CALIBRATION	reading of data from TCU
	T	TRANSMIT_CALIBRATION	transfer of calibration data to memory of TCU
	R	READ_DATA	reading of data stored in TCU
	V	VIEW_DATA	display of stored data in TCU
	P	PRINT_DATA	printing of data stored in TCU
Calibration <sup>2)</sup>	T	THROTTLE	data loading for the relevant throttle pos. calib.
Data sets	F	FILE	submenu for selecting and loading of TCU control data
TCU-control data <sup>3)</sup>	E	EDIT	submenu for display and load of control data
	S	SPEED	speed coordinates for PID regulator
	L	LOAD	throttle position coordinates for PID regulator
	P	PID	PID factors
	F	FUNCTIONS	subprogram for viewing of the correction function
	P	PRESSURE_LOAD	target input servo position - airbox pressure
	T	TEMPERATURE_CORR	correction of target pressure governed by airbox temperature
	K	KNOCK_CORR	irrelevant, not active
	S	SERVO_CORR	correction of target input of wastegate pos. governed by airbox temp.
	C	CONSTANTS	display of various constants
	Q	QUIT	exit from the communication program

<sup>1)</sup> contains the most important data for the maintenance

<sup>2)</sup> effective only in conjunction with a TCU

<sup>3)</sup> for information only

04056

# Program version TLR 4.5 and TLR 4.6

fig.72a

user field	key	point of menu	brief description
	Esc		exit from the respective sub program, back to the main menu
choice of graphic adapter	V C E	V G A C G A E G A	option to choose VGA-graphic card option to choose CGA-graphic card option to choose EGA-graphic card
choice of interface	1 2	COM1 COM2	manual dialing of COM1 interface manual dialing of COM2 interface
On-line-display <sup>1)2)</sup>	M L 1 2	MONITOR LOG 1_SCOPE 2_SCOPE	display of engine data ON/OFF of engine data recording display deviation (AIRBOX-pressure to SETPOINT-pressure) display (AIRBOX-pressure and SETPOINT-pressure)
Calibration-data <sup>1)</sup>	C S T C R T R V P	CFG/DAT SETUP TRANSMIT_SETUP CALIBRATE READ_CALIBRATION TRANSMIT_CALIBRATION READ_DATA VIEW_DATA PRINT_DATA	submenu, calibration and TCU data analysis submenu for input of serial number and hours of Setup data transfer to TCU display (SERVO, THROTTLE, pressure sensor) reading of data from TCU transfer of calibration data to memory reading of data stored in TCU display of stored data in TCU printing of data stored in TCU
Calibration <sup>2)</sup>	T	THROTTLE	data loading for the relevant throttle pos. calib.
Data sets	F	FILE	submenu for selecting and loading of TCU control data
TCU-control data <sup>3)</sup>	E M F P T K S C	EDIT MAP FUNCTIONS PRESSURE_LOAD TEMPERATURE_CORR KNOCK_CORR SERVO_CORR CONSTANTS	submenu for display of TCU control data data set for indication of characteristics subprogram for viewing of the correction function target input servo position - airbox pressure correction of target pressure governed by airbox temperature irrelevant, not active correction of target input of wastegate pos. governed by airbox temp. display of various constants
	Q	QUIT	exit from the communication program

<sup>1)</sup> contains the most important data for the maintenance

<sup>2)</sup> effective only in conjunction with a TCU

<sup>3)</sup> for information only

00767

Initial issue

Reference

Subject: TLR 4.3  
TLR 4.5  
TLR 4.6

Date  
1999 09 01

Page  
49

## 16) ERROR Detection Chart

display	target	actual (1)	possible reason (5)	orange lamp	red lamp
SPEED	engine speed (~1500 ÷ 5800)	n = Ø	engine shut down	off	off
		n = Ø	faulty rev-pickup, gap of pickup too big	off	off
		n = Ø	circuit break (15)	off	off
		n = Ø	circuit break (27)	off	off
		n = Ø	short circuit (13 to 26)	off	off
		n = Ø	short circuit (15 to GND)	off	off
		n = Ø	short circuit (13 to GND)	off	off
LOAD	0 bis 115%	idling > 3% full load < 113%	defective potentiometer misadjustment of throttle pos./new cal. required	off	off
		0%	severed plug connection on pot.	flashing	off
		0%	circuit break (8)	flashing	off
		0%	circuit break (20)	flashing	off
		115%	circuit break (32)	off	off
		0%	short circuit (8 to GND)	flashing	off
		0%	short circuit (20 to 8)	flashing	off
		I/O error <sup>(4)</sup>	short circuit (20 to GND)	off	off
AMBIENT PRESS	ambient pressure (~ 990 mbar)	1000 mbar	severed plug connector on sensor	flashing	off
		ca. 350 mbar	air box pressure sensor connected	off	off
		ambient pressure <sup>(6)</sup>	airbox pressure hose connected	off	off
		1000 mbar	circuit break (6)	flashing	off
		1000 mbar	circuit break (18)	flashing	off
		ca 1300 mbar	circuit break (30)	off	off
		1000 mbar	short circuit (6 to GND)	flashing	off
		1000 mbar	short circuit (6 to 18)	flashing	off
AIRBOX PRESS.	airbox pressure (ambient pressure) <sup>(7)</sup>	I/O error <sup>(4)</sup>	short circuit (18 to GND)	off	off
		1500 mbar	severed plug connection on sensor	flashing	off
		ca. 2100 mbar	ambient pressure sensor connected	off	off
		ambient pressure <sup>(6)</sup>	airbox pressure hose not connected/kinked	off	off
		1500 mbar	circuit break (9)	flashing	off
		1500 mbar	circuit break (21)	flashing	off
		ca. 2700 mbar	circuit break (33)	off	off
		1500 mbar	short circuit (9 to GND)	flashing	off
AIRBOX TEMP.	air temp. in airbox	1500 mbar	short circuit (9 to 21)	flashing	off
		I/O error <sup>(4)</sup>	short circuit (21 to GND)	off	off
		50°C	severed plug connection to sensor	flashing	off
		50°C	faulty temperature sensor	flashing	off
		50°C	conn. temp. sensor mistaken for solenoid valve	flashing	off
		50°C	circuit break (3)	flashing	off
SERVO POSITION	0% to 100%	50°C	circuit break (4)	flashing	off
		50°C	short circuit (4 to GND)	flashing	off
		< 0%	severed plug connection Servopoti. 3 pole	off	off
		restrained	severed plug connection Servomotor 2 pole	off	off
		restrained	circuit break (2)	off	off
		ca. -10%	circuit break (7)	off	off
		restrained	circuit break (14)	off	off
		< 0%	circuit break (19)	off	off
		cont. changing	circuit break (31)	off	off
		I/O error <sup>(4)</sup>	short circuit (7 to 31)	off	off
		> 100%	short circuit (7 und 19)	off	off
		restrained <sup>(4)</sup>	short circuit (19 to GND)	off	off
		restrained	short circuit (2 to 14)	off	off
		restrained	short circuit (2 to GND)	off	off
		undef./restrained	short circuit (14 to GND)	off	off

<sup>(1)</sup> possible default values

<sup>(2)</sup> at automatic re-activation of the TCU, auto test of servo motor and lamps is performed

<sup>(3)</sup> SETPOINT = target pressure input for airbox

<sup>(4)</sup> I/O error = circuit break TCU to computer or short circuit in voltage supply to TCU

01146

possible effect on TCU	possible effect on engine
none	no target pressure correction by excessive engine speed
none	no target pressure correction by excessive engine speed
none	no target pressure correction by excessive engine speed
none	no target pressure correction by excessive engine speed
none	no target pressure correction by excessive engine speed
none	no target pressure correction by excessive engine speed
none	no target pressure correction by excessive engine speed
confined target pressure range	performance loss
sudden target pres. changes, fixed target pres.	
setpoint 1500 mbar <sup>(3)</sup>	wastegate closes completely, no control possible
setpoint 1500 mbar <sup>(3)</sup>	wastegate closes completely, no control possible
setpoint 1500 mbar <sup>(3)</sup>	wastegate closes completely, no control possible
setpoint 1350 mbar <sup>(3)</sup>	engines runs with take-off performance, no control possible
setpoint 1500 mbar <sup>(3)</sup>	wastegate closes completely, no control possible
setpoint 1500 mbar <sup>(3)</sup>	wastegate closes completely, no control possible
TCU stops <sup>(2)</sup>	wastegate restrained, no control possible
incorrect setpoint of wastegate pos.	as of approx. 950 mbar wastegate is not closing enough, performance loss
incorrect setpoint of wastegate pos. <sup>(8)</sup>	wastegate closes too far - possible performance rise
incorrect setpoint of wastegate pos.	wastegate closes too far - pressure rise, no overboost warning
incorrect setpoint of wastegate pos.	wastegate is not closing enough - performance loss
incorrect setpoint of wastegate pos.	wastegate is not closing enough - performance loss
incorrect setpoint of wastegate pos.	wastegate is not closing enough - performance loss
incorrect setpoint of wastegate pos.	wastegate is not closing enough - performance loss
incorrect setpoint of wastegate pos.	wastegate is not closing enough - performance loss
TCU stops <sup>(2)</sup>	wastegate restrained, no control possible
target pressure correction not possible	wastegate is not closing enough - performance loss
target pressure correction not possible <sup>(8)</sup>	wastegate closed too far - possible performance rise
incorrect setpoint of wastegate pos.	wastegate closed too far - pressure rise, no overboost warning
target pressure correction not possible	wastegate is not closing enough - performance loss
target pressure correction not possible	wastegate is not closing enough - performance loss
target pressure correction not possible	wastegate is not closing enough - performance loss
target pressure correction not possible	wastegate is not closing enough - performance loss
target pressure correction not possible	wastegate is not closing enough - performance loss
TCU stops <sup>(2)</sup>	wastegate restrained, no control possible
temp. correction of MAP impossible (const +5%)	neither temp. limitation nor power adaptability in regard to ambient conditions
temp. correction of MAP impossible (const +5%)	neither temp. limitation nor power adaptability in regard to ambient conditions
temp. correction of MAP impossible (const +5%)	neither fuel enrichening nor temperature limitation
temp. correction of MAP impossible (const +5%)	neither temp. limitation nor power adaptability in regard to ambient conditions
temp. correction of MAP impossible (const +5%)	neither temp. limitation nor power adaptability in regard to ambient conditions
temp. correction of MAP impossible (const +5%)	neither temp. limitation nor power adaptability in regard to ambient conditions
none	wastegate closes completely, no control possible
none	no control possible
none	no control possible
none	wastegate opens fully - performance loss
none	no control possible
none	wastegate closes completely, no control possible
none	wastegate opens fully - performance loss
TCU stops <sup>(2)</sup>	wastegate opens fully - performance loss
TCU stops <sup>(2)</sup>	wastegate opens fully - performance loss
TCU stops <sup>(2)</sup>	wastegate restrained, no control possible
none	no control possible
none	no control possible
none	no control possible

<sup>(5)</sup> relevant defective TCU component

<sup>(6)</sup> shortcoming perceptible only at engine operation

<sup>(7)</sup> at engine operation up to approx. 1350 mbar

<sup>(8)</sup> MAP 100% ± (temp. corr.) - (20% setpoint corr.)

04057

Blank page

