Part numbers of the copper sealing rings

.... that are installed on the engine and their sizes

Rotex P/N	size	used with
230 415	6 x 10	**water pump synchronization connection on the intake manifold**
950 141	8 x 13	**Fuel connection on carburetor Blocking pin screw plug Pressure oil line on turbocharger with valve housing (also 915)**
950 143	8.2 x 13 x 1.4	**Fuel distributor for flexible fuel lines**
230 150	10 x 14	**Pressure oil line Governor Fuel connections 914**
250 425	10.2 x 15 x 1.5	**Connections for fuel pump 893115**
250 646	12 x 18	**Valve housing for turbocharger (also 915) Fuel line 912 iS - also connection to fuel pressure regulator**
250 010	12 x 18	**Oil retaining drain plug (with insert)**
250 015	12 x 18	**for airbox temperature sensor 912 iS**
230 387	14.2 x 18 x 2	**Screw connection oil pump\\oil cooler connection**
430 622	16 x 22	**Ring hose nipple for oil return - also screw connection oil pump 912 iS**

... is of course not complete ...

From:
https://kleinjung.de/rotax/ - **Ralle's ROTAX FAQ**

Permanent link:
https://kleinjung.de/rotax/doku.php?id=en:pn-copper_sealing_rings

Last update: **14.02. 2025 08:31**