The lubrication system

Check engine oil level
.... or, how do I make the oil reservoir burp?

---

permanent oil pressure fluctuations during operation
.... when the needle trembles or the numbers don't come to rest...

Check the old, mechanical VDO oil pressure sensor
.... this is still in operation in many cars and likes to go crazy.
is still a work in progress

From:
https://www.kleinjung.de/rotax/ - **Ralle's ROTAX FAQ**

Permanent link:
https://www.kleinjung.de/rotax/doku.php?id=en:lubrication_system

Last update: **10.02. 2025 07:38**