

Ignition housing

where the generator and the water pump are located

the leakage hole on the ignition housing
... mostly well hidden holes and their meaning...

From:
<https://kleinjung.de/rotax/> -

Permanent link:
https://kleinjung.de/rotax/doku.php?id=en:ignition_housing

Last update: **10.02. 2025 07:29**

